

# **USER MANUAL**

Please read this manual throughly before using this product and keep it for future reference.

#### **PACKING LIST**



Projector



Remote



**User Manual** 



AV Cable



Power Cable



### NOTICE

### Recommended



### NOT Recommended















### **FUNCTION OVERVIEW**





( Multimedia version )

## **QUICK START**



Plug the power cord into an outlet



Select the correct input source to project your device.



Press the power button to turn off the projector.



Press the power button to turn on the projecto r.



Focus ring to get the best image performance.

#### INPUT SOURCE

Press = on the remote to enter the interface of input source.


#### A. USB Connection




#### B. HDMI Connection



#### PROJECTOR CONNECTION



### PROJECTION DISTANCE&SIZE



### **SPECIFICATION**

Display technology	LCD	Light Source	LED
Power supply	AC 100-240V 50/60Hz	Resolution Supported	576i, 576P, 720i, 720P, 1080i, 1080P
Projection Distance	3.8FT-18FT (1.16M-5.5M)	Projection Screen	37" - 170"
Installation Type	Front/Rear/Ceiling	Aspect Ratio	4:3/16:9/Auto
Focus	Manual	Ports	HD In*1/USB2.0 Port*1/ AV In*1/Audio Out*1/
Speaker	3W/4ohm	Unit Net Weight	2.2 lb (1 kg)
Unit Dimension	6.45*6.3*6.77 inch	Audio Format Supported	MP2/MP3/PCM/FLAC/WMA
Photo Format Supported	BMP/JPG/PNG/ GIF/JPEG	Video Format Supported	AVI/MP4/MKV/FL/MOV/ RMVB/3GP/MPEG1/ MPEG2/H.264/XVID

# TROUBLESHOOTING GUIDE

- 1. Blurry Image
- \* Adjust electronic focus/keystone.
- \* Projector and screen/wall must be in effective distance.
- 2. Remote unresponsive
- \* Make sure remote points at IR receiver directly.
- \* Do not cover IR receiver.
- 3. Up Side Down Images Enter "Menu" on projector or remote to flip the projection image.

# Projection mode/Bluetooth speaker (only Android version)



Indicator status is as below at the power button:

Standby mode: red light Working mode: blue light Speak mode: blue light

After short pressing the power button, the projector is on:

Enter speaker mode. In the working state, short press the power button to switch to speaker mode. After entering the speaker mode for 20 seconds, it will automatically enter the Bluetooth standby state

Exit speaker mode: In the speaker mode, short press the power button or any key on the remote control to exit speaker mode, and enter projection mode

8

